

BAK-UP USA

INSTALLATION GUIDE

BMW R1200GS DRIVER'S BACKREST 07 & UP

- 1. REMOVE THE PILLION SEAT & TURN IT UPSIDE DOWN**
- 2. INSTALL THE (4) 6mm WELL NUTS IN THE (4) HOLES IN THE BOTTOM OF THE PILLION SEAT.**
- 3. PLACE YOUR NEW BACKREST OVER THE FRONT OF THE PILLION SEAT SO THAT THE HOLES IN THE BACKREST ALIGN WITH THE WELL NUTS.**
- 4. START THE SCREWS IN THE (2) BACK HOLES AND LEAVE THEM LOOSE.**
- 5. SLIDE THE (2) SPACERS UNDER THE FRONT TO ALIGN WITH THE FRONT HOLES IN THE BRACKET, & INSTALL THE SCEWS.**
- 6. TIGHTEN ALL (4) SCREWS & REINSTALL THE PILLION SEAT ON THE BIKE.**
- 7. ADJUST TO YOUR LIKING.**

GET ON YOUR BIKE AND RIDE !

****PERIODICALLY** CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**

