

BAKUP-USA

Installation Guide

BMW R1100/1150RT Driver

- 1. Remove the rider and passenger seats.**
- 2. Remove the two locating ramps brackets for the rear of the rider's seat and set aside.**
- 3. Using a 10mm wrench, remove the two (2) 10mm bolts to frame and install the backrest (one each side) using the same bolts to reinstall and torque the bolts to factory specifications.**
- 4. Reinstall the seats and adjust to your liking.**

***Note**

It may be necessary to compress the front of the rear seat to insure that the bracket does not interfere with the seat cover on installation.

GET ON YOUR BIKE AND RIDE!

TOOLS NEEDED: 4mm Allen Wrench (included in RT tool kit) & 10mm Socket