

# **BAKUP-USA**

## **Installation Guide**

### **KAWASAKI VULCAN 1700 Nomad/Voyager Driver's Backrest**

- 1. Remove the pillion seat from your bike and place it upside down on a workbench.**
- 2. Using a 10mm wrench remove the (2) two nuts and the bracket from the bottom of the pillion seat.**
- 3. Place your backrest over the front of the pillion seat and the (2) two mounting holes over the studs for the pillion seat bracket.**
- 4. Reinstall the pillion seat bracket on top of the backrest bracket.**
- 5. Install the two (2) rubber bumpers (provided with your backrest) on top of the two rubber bumpers on the bottom front of the pillion seat.**
- 6. Reinstall the two (2) nuts and tighten.**
- 7. Reinstall the pillion seat on the bike and adjust to your liking.**

***GET ON YOUR BIKE AND RIDE!***