

# **BAKUP-USA**

## **Installation Guide**

### **KAWASAKI VULCAN 1600 Nomad Driver's Backrest**

- 1. Place your bike in a safe location.**
- 2. Remove the pillion seat.**
- 3. Remove the one screw that holds the forward bracket for the pillion seat directly behind the driver's seat.**
- 4. Place your backrest atop the forward pillion seat bracket so that the hole aligns. Reinstall the screw.**
- 5. Reinstall the pillion seat.**
- 6. Adjust to your liking.**

***GET ON YOUR BIKE AND RIDE!***