

# **BAKUP-USA**

## **Installation Guide**

### **VICTORY Kingpin-Vegas Standard/Tour Driver's Backrest**

1. Remove the plastic side covers.
2. Remove the 2 fender trim chrome strips.
3. Remove the Driver and Passenger seats.
4. Remove the (2) bolts on the front fender using a 10mm wrench.
5. Place your backrest so that the holes in the bracket align with the forward holes for the fender trim.
6. Install the (2) screws in the front holes. Be sure that the washers are between the fender and bracket.
7. Install the Passenger seat and tighten all screws.
8. Install the chrome fender trim.
9. Install the Driver's seat and side covers.
10. Adjust to your liking. *We've got your back!*

***GET ON YOUR BIKE AND RIDE!***